

Temperature sensor PT-100 or PT-1000 including built-in reference body

For external temperature recording or monitoring,
we provide a temperature sensor PT 100 or PT 1000 including
built-in reference body (measurement bottle or refrigerating
block) which will be incorporated in our refrigerators or free-
zers.

The temperature sensors can be connected via appropriate in-
terface on site, e.g. RS 232.

The Sensor can be connected to a computer system or another
local temperature analysis unit. A 4 –wire PT-sensor that complies
with DIN IEC 751, Class 1/ B is used here.



Fig.: temperature sensor with measurement bottle as built-in
reference body

If you have any questions, please contact us.
We will be pleased to assist you.

Philipp Kirsch GmbH

Manufacturer of refrigeration technology for the health sector
Im Lossenfeld 14
77731 Willstätt | Germany
Tel.: +49 (0) 781 9227-0
Fax: +49 (0) 781 9227-200
info@kirsch-medical.com
www.kirsch-medical.com